


BENDER to XYZ



BENDER to XYZ

Bender to XYZ User Guide

*Converts Bender data to
Centerline XYZ data.*



2548 Campbellgate Dr • Waterford • MI • 48329
Tel: (248) 674-2059 • Fax: (248) 674-2396

© 2016 Advanced Tubular Technologies, Inc. All rights reserved

Bender to XYZ Calculator

© 2016 Advanced Tubular Technologies, Inc. All rights reserved

All rights reserved. No parts of this work may be reproduced in any form or by any means - graphic, electronic, or mechanical, including photocopying, recording, taping, or information storage and retrieval systems - without the written permission of the publisher.

Products that are referred to in this document may be either trademarks and/or registered trademarks of the respective owners. The publisher and the author make no claim to these trademarks.

While every precaution has been taken in the preparation of this document, the publisher and the author assume no responsibility for errors or omissions, or for damages resulting from the use of information contained in this document or from the use of programs and source code that may accompany it. In no event shall the publisher and the author be liable for any loss of profit or any other commercial damage caused or alleged to have been caused directly or indirectly by this document.

Printed: October 2016 in Waterford, Michigan

Publisher

Advanced Tubular Technologies

Author


Michael Cone

Table of Contents

Part I Introduction	1
1 How to Install The Benderlink Software	5
2 Bend Data	11
3 Data Types Combinations	13
4 Bend Calculation Setup	15
5 Errors Display	17
Part II Bender Data Elements	19
1 Incremental Length	23
2 Absolute Length	25
3 Incremental Rotation	29
4 Absolute Rotation	31
5 Rotation Direction	33
6 Bend Angle	38
7 Bend Type	40
8 Centerline Radius	41
Part III Foundational Data	43
1 Conversion of Values	47
2 Inserted Rows Results	49
Index	55

BENDER_{to}XYZ

Part



1 Introduction



Bender to XYZ is the most flexible calculator in the world for calculating data from an assortment of bender data types to centerline XYZ coordinates. In fact, there are 12 possible combinations of bender data types.

The choices for bend data entry depend on the following factors:

1. Is the LENGTH data Incremental or Absolute?
2. Is the ROTATION data Incremental or Absolute?
3. Is the BENDING type DRAW or COMPRESSION?
4. Is the ROTATION DIRECTION positive Counter Clockwise or Clockwise?

These four factors control all the possible combinations of bender data that can be entered into Bender to XYZ.


1.1 How to Install The Benderlink Software

STEP 1

Run the setup.exe program.

Click on "I accept the agreement"


Press Next



STEP 2

Copy the password supplied to you by email. Click on the Password field, then press "Ctrl-V" key combination to paste the password.


Press Next



STEP 3

This window contains revision notes.


Press Next



STEP 4


The program will install when you press Install.

Press Install




STEP 5

This is the final screen. Insert the hardware key into an available USB port then...

Press Finish

STEP 6

The program will display if the hardware key is found and license is verified.



1.2 Bend Data


INCREMENTAL BEND DATA

Incremental data is the most common bender data format used in the tube fabrication industry to program bend data.

Incremental data is usually referred to with an acronym that directly relates to three axes on a standard horizontal CNC Bender. LRA, FRB, YBC, FPB, PRB, are all variations of the incremental bender formats used in the industry. All of them can be entered into the Bender to XYZ software.


For "LRA", "L" refers to LENGTH, "R" refers to ROTATION, and "A" refers to bend ANGLE.

This is an example of **FRB** data in Advanced Tubular's CNC Bender software:



ABSOLUTE BEND DATA

The other (and less common) format is **Absolute** bender data. Absolute bender data is common in military charts using MIL-D-9898 as shown here:



Also, Conrac benders (no longer manufactured - but still available in the industry) use absolute lengths and rotations.

DESCRIBED in BEND DATA ELEMENTS

Both incremental and absolute formats are described in this document.

1.3 Data Types Combinations

FLEXIBLE BENDER TYPE COMBINATIONS

Bender to XYZ is the most flexible converter in the world because it allows you to choose the type of data that is entered in each *column* of data.


Because of this column setup approach, the software can calculate at least 12 different combinations of data (12 different styles of bender data charts)

	LENGTH TYPE	ROTATION TYPE	BEND TYPE
1	Incremental Lengths	Incremental Rotations CCW	Draw Bend
2	Incremental Lengths	Incremental Rotations CW	Draw Bend
3	Incremental Lengths	Absolute Rotations CCW	Draw Bend
4	Incremental Lengths	Absolute Rotations CW	Draw Bend
5	Absolute Lengths	Incremental Rotations CCW	Draw Bend
6	Absolute Lengths	Incremental Rotations CW	Draw Bend
7	Absolute Lengths	Incremental Rotations CCW	Compression Bend
8	Absolute Lengths	Incremental Rotations CW	Compression Bend
9	Absolute Lengths	Absolute Rotations CCW	Draw Bend
10	Absolute Lengths	Absolute Rotations CW	Draw Bend
11	Absolute Lengths	Absolute Rotations CCW	Compression Bend
12	Absolute Lengths	Absolute Rotations CW	Compression Bend

1.4 Bend Calculation Setup

SETUP for BENDER DATA TYPE

The Calc Setup button on the main screen allows you to load the Bend Calculation Setup dialog to control each of the data types. This is an image of the dialog:



The image shows a dialog box titled "Calc Setup" with three sections, each containing radio button options:

- Length Type**
 - Incremental Length
 - Absolute Length
- Rotation Direction**
 - Positive CCW
 - Positive CW
- Rotation Calculation**
 - Incremental Rotation
 - Absolute Rotation

Each of these type settings is explained in the different topics of this document.

1.5 Errors Display

ERROR DISPLAY METHOD


Bender to XYZ changes the color of a bender cell to **red** if it senses a problem that needs to be resolved before continuing. Other sections of this manual explain how to understand the problems that could occur and how to resolve them.

	Length	Rotation
1	100.00	-----
2	abc	90.00
3	100.00	180.00
4	100.00	-90.00
LL	100.00	-----

So - remember that **red-filled** cells indicate a problem in the bender data grid. These are guidelines how to resolve data entry problems.

BENDER_{to}XYZ

Part



2 Bender Data Elements


This section explains the various lengths and angle types possible in Bender to XYZ.

2.1 Incremental Length

Incremental lengths is simply the *lengths between bends* . So if you know that your bender data indicates that the length **between** bends 1 and 2 is (for example) 100 millimeters, then you would use the incremental length setup to enter data.

SETUP

The incremental length type can be set by clicking on the Calc Setup button in the main screen, then choosing the Incremental Length radio button like this:



NON-NUMERIC VALUES

	Length	Rotation
1	100.00	-----
2	abc	90.00
3	100.00	180.00
4	100.00	-90.00
LL	100.00	-----

It is possible to enter a non-numeric value in the field. For example, try typing a negative sign in any field and watch what happens. A "-" symbol by itself is not a proper number, so the field turns red until you enter a number after the negative sign.

Alpha characters are not legal in the length field. Change the value to a floating point number only.

Note about NEGATIVE LENGTH VALUES

A **negative** incremental length value is not a useful real value in the real world. For real-world tube fabrication situations, incremental lengths must be ZERO or POSITIVE. (In the case of ZERO, then the two bends would touch each other at the tangent points.) If your data shows a negative length value, then you will want to adjust the data so that the length is equal to or greater than zero.

2.2 Absolute Length

The best way to visualize **absolute lengths** is to think of distances along the length of the bed of a bender using a tape measure stretched from one end of the bender to the other end.



Older Conrac benders actually used metal tape measures riveted along the bed of the bender. The start of the tape is placed at the tangency of the bend die (where the bending begins). The end of the tape is stretched toward the back of the bender along the bender bed. The further the carriage is from the bend die, the higher the carriage position is on the tape.


The image below is a sample of how the lengths appear for a sample tube. The cut length of the tube shape is 1800 millimeters, and the position of the carriage to place the tube forward in position for the first bend is "1710". So the first straight is equal to 1800mm - 1710mm, or **90 millimeters in length**. In an incremental length cell, we would enter "90", but here the proper value is 1710. Both values create the same part. The difference is the setup is changed from incremental to absolute length.

	Length
1	900.00
2	721.46
3	595.11
4	468.93
LL	100.00

CUT LENGTH is IMPORTANT


The CUT LENGTH value in General Setup is an important part of the calculation for Absolute Lengths. Without a proper cut length, it is not possible to interpret and calculate true Absolute values.

This is an example of how an incremental length is converted to an absolute length. Note the effect that cut length has on the calculation of the first straight. (Straight-length calculations after the first straight are more complex - but this example will give you a demonstration of why cut length is important for absolute lengths.)



SETUP

The Absolute Length type can be set by clicking on the Calc Setup button in the main screen, then choosing the Absolute Length radio button like this:

**SOLVING NEGATIVE VALUES**

Often these negative errors are due to the **CUT LENGTH** not large enough. Remember that the CUT LENGTH should logically be greater than (or longer than) any of the values in the absolute length data that is displayed in the ABSOLUTE Length mode. Increase the CUT LENGTH in the general setup menu until none of the lengths in the bender data are negative.

Letters are not legal in the length fields.

2.3 Incremental Rotation


Incremental rotations are twist angles between bends that can be any numeric value. Each rotation is measured between only two adjacent bends. There is no accumulation of values as there is with Absolute rotations. So think of the rotation value as the actual twist between the **current bend plane** and the **next bend plane**.

Sample Incremental Rotation Type (See the rotation column):

	Length	Rotation	Bend	Radius
1	900.00	-----	90.00	50.00
2	721.46	90.00	30.19	50.00
3	595.11	180.00	30.00	50.00
4	468.93	-90.00	0.27	50.00
LL	100.00	-----	-----	-----

SETUP

The Incremental Rotation type can be set by clicking on the Calc Setup button in the main screen, then choosing the Incremental Rotation radio button like this:



ENTRY RANGE:-360 to +360

Any value that *exceeds* the range of -360 to +360 degrees is automatically reduced to within that range and is therefore not considered an error.

NEGATIVE VALUES are OK

Negative values are acceptable.

NON-NUMERIC VALUES are OK

Special non-numeric values can be used to indicate a **degree-minute-second** format. This is how to use this format:

1. The letter "d" follows the degree value
2. An apostrophe (') follows the minute value
3. A quotation mark (") follows the second value

For example: **90d25'20"** is a valid angle and is converted to 90.422222222222 internally before displaying "9.42" in the cell.

Other valid ways to enter data are:

90d
90d25'

90d20"
90d25'20"

Sample angle using this format:

	Rotation	A
X0	-----	
X0	90.00	
X0	135d30'15"	
X0	-----	

PROPER ORDER

Any combination of these symbols ***in the proper order*** is acceptable. If they are out of order (like 25'90d) then an error will occur. Correct the order, and the value will become legal.

Any other letters or symbols are invalid.

2.4 Absolute Rotation

Absolute rotations are twist angles between bends that can be any numeric value. Each rotation is dependent on the values of all preceding rotations because they accumulate from all preceding rotations. These rotations are also, like incremental rotations, used to measure between two adjacent bends. But remember that they accumulate from all preceding bend rotations.

Compare Incremental to Absolute Rotations

Compare the two rotation types in these two samples:

Sample Incremental Rotation Type (see the rotation angles):


	Length	Rotation	Bend	Radius
1	900.00	-----	90.00	50.00
2	721.46	90.00	30.19	50.00
3	595.11	180.00	30.00	50.00
4	468.93	-90.00	0.27	50.00
LL	100.00	-----	-----	-----

The same data with Absolute Rotation Type (see the rotation angles)

	Length	Rotation	Bend	Radius
1	900.00	-----	90.00	50.00
2	721.46	90.00	30.19	50.00
3	595.11	270.00	30.00	50.00
4	468.93	180.00	0.27	50.00
LL	100.00	-----	-----	-----

SETUP

The Absolute Rotation type can be set by clicking on the Calc Setup button in the main screen, then choosing the Absolute Rotation radio button like this:



RANGE:-360 to +360

Any value that exceeds the range of -360 to +360 degrees is automatically reduced to within that range and is therefore not considered an error.

NEGATIVE VALUES are OK

Negative values are acceptable.

NON-NUMERIC VALUES are OK

Special non-numeric values can be used to indicate a **degree-minute-second** format. This is how to use this format:

1. The letter "d" follows the degree value
2. An apostrophe (') follows the minute value
3. A quotation mark (") follows the second value

For example: **90d25'20"** is a valid angle and is converted to 90.422222222222 internally before displaying "9.42" in the cell.

Other valid values are:

- 90d**
- 90d25'**
- 90d20"**
- 90d25'20"**

Sample angle using this format:

	Rotation	A
X0	-----	
X0	90.00	
X0	135d30'15''	
X0	-----	

PROPER ORDER

Any combination of these symbols **in the proper order** is acceptable. If they are out of order (like 25'90d) then an error will occur. Correct the order, and the value will become legal.

Any other letters or symbols are invalid.

2.5 Rotation Direction


Positive = CCW



Common

On most benders, in setting the direction of the rotation, it is often assumed that the positive angle values rotate consistently in one direction (*see note 1 below*). The question is then, "in which direction is the positive rotation rotating?"

Most benders seem to use the same direction as general CAD programs like AutoCAD. They rotate the positive Counter Clockwise when the collet is viewed from the front of the bender.




However, there are cases where a bender may consider CW the "positive" direction. If the bender data you are converting to XYZ coordinates is one of those benders, then it is important that you choose the Positive CW radio button option.

Positive = CW



Uncommon



EFFECT OF SWITCHING the DIRECTION

The effect of switching between CCW positive and CW positive rotations, is the inversion of all the Z values. Inversion is multiplying the all values by negative 1 - which changes the sign of the value.

See the effect of changing the meaning of "positive rotation" in these two XYZ data charts.

This is with positive rotations set to CCW (see the Z values):

Point	X	Y	Z	Radius
1	0.00	0.00	0.00	----
2	150.00	0.00	0.00	50.00
3	150.00	163.49	0.00	50.00
4	150.00	273.16	63.81	50.00
5	150.00	400.08	64.23	50.00
6	207.22	498.13	64.55	----



This is with positive rotations set to CW (see the Z values):

Point	X	Y	Z	Radius
1	0.00	0.00	0.00	-----
2	150.00	0.00	0.00	50.00
3	150.00	163.49	0.00	50.00
4	150.00	273.16	-63.81	50.00
5	150.00	400.08	-64.23	50.00
6	207.22	498.13	-64.55	-----



Benders that Switch Rotation Directions in the Middle of a Part

Most benders don't switch the meaning of positive or negative rotations in the middle of a part. It is more logical to leave the definition of the rotation positive plus and minus the same direction - even if running a dual head bender.

However watch out for dual-head benders do switch the rotation meaning of positive depending on the head being used. For example, the Schwarze-Robitec dual-head benders does this reversal. The bender is designed to use one carriage assembly with two bend arms as shown in the image below.

Also, older (pre-2016) dual-head SOCO benders would switch the rotation depending on which head was bending. SOCO fixed this issue as of 2016.

Schwarze-Robitec "Typ CNC 60 E Twin TB MR - teilelektrisch" bender:



2.6 Bend Angle

Bend angles are degrees of bend and are positive values only.

RANGE: Positive Values Only

Any value that is negative is considered an error. Change the value to a zero or a positive value.

NON-NUMERIC VALUES are OK

Special non-numeric values can be used to indicate a **degree-minute-second** format. This is how to use this format:


1. The letter "d" follows the degree value
2. An apostrophe (') follows the minute value
3. A quotation mark (") follows the second value

For example: **90d25'20"** is a valid angle and is converted to 90.422222222222 internally before displaying "9.42" in the cell.

Other valid values are:

90d
90d25'
90d20"
90d25'20"

Sample angle using this format:



	Rotation	A
X0	-----	
X0	90.00	
X0	135d30'15"	
X0	-----	


PROPER ORDER

Any combination of these symbols **in the proper order** is acceptable. If they are out of order (like 25'90d) then an error will occur. Correct the order, and the value will become legal.

Any other letters or symbols are invalid.

2.7 Bend Type

DRAW BEND or COMPRESSION BEND




The bend type can be either DRAW or COMPRESSION when the ABSOLUTE LENGTH radio button is checked. The type of bend has an impact on the calculation of the ABSOLUTE LENGTH data in a bend data set with absolute lengths. When the INCREMENTAL Length button is checked, then there is no choice - the bend type is not significant to the length calculations.

Draw Bend

A DRAW bend is a bend where the bend die rotates and draws the tube shape into the die for bending. This type of bending controls the flow of the material with more precision than compression bending.

This is a draw bender pulling the tube around the bend die:




Compression Bend

A COMPRESSION bend is a bend where the bend die is stationary during bending and the tube is compressed or wiped around the die. In this style of bending, the bend die does not rotate, but the clamp that holds the tube to the die rotates around the die to form the bend.

Compression bending is often used on dedicated bending machines that bend a single shape. The tube is placed in the machine, then the bends are placed on the tube from the outside toward the middle. The value of compression bending is speed - it is very fast.

2.8 Centerline Radius

Centerline Radius



Centerline radius values follow same rules as length values. They represent the radius values from the nominal centerline of the tube to the center of the bend radius.

NEGATIVE VALUES


A **negative** radius value is not a useful real value when the LRA data. Negative radii cannot exist. In this case, you will want to adjust the data so that the length is equal to or greater than zero.

NON-NUMERIC VALUES

Alpha characters are not legal in the length field. Change the value to a floating point number only.

BENDER_{to}XYZ

Part



3 Foundational Data


"Foundational data" is the data that is stored at its lowest level internally by Bender to XYZ data. As you will see here, the only data that is stored - either in memory or in files - is incremental data.

DATA STORAGE INTERNALLY

If any column of data is displaying ABSOLUTE data, and you enter a change, then an automatic conversion occurs in real-time (as you type) to the equivalent incremental data. This means that the conversion happens automatically every time you change a digit in any of the numbers on the screen.

This same incremental bender data is stored to disk and used for recall in the future sessions. Using only incremental data for storage means that the file data will present a consistent set of incremental LRA data for any other program that loads and uses the Bender to XYZ data file.

This is an example of how this conversion occurs with ABSOLUTE LENGTHS:



SENDING DATA to the DISPLAY


When data is displayed, conversion happens in the opposite direction. The data is converted from the internal incremental data to the screen data, the calculator converts the data into the format that is appropriate based on the Bend Calculation Setup dialog state.

3.1 Conversion of Values

Absolute values are always converted to incremental values for storage internally before the XYZ data is calculated. This is a demonstration of how this principle works with the first length entry made using ABSOLUTE mode.

ENTERING DATA in the GRID

Examine what happens when you enter data when the length column is displaying data in ABSOLUTE mode.




UPDATING the GRID DISPLAY from the DATABASE

This is nearly the opposite process shown above.

- The incremental length of 10 mm is stored internally.
- Bender to XYZ knows that it needs to upgrade the data in the grid.
- The data setup indicates that the length data is to be displayed in ABSOLUTE mode.
- So an automatic calculation must occur before the data is displayed on the screen.

This is how the process works internally:



While the calculations are more complex for other values, the principle is the same.

3.2 Inserted Rows Results

UNEXPECTED INSERTION RESULTS


Because of the way Bender to XYZ calculates data from a foundation of incremental data, inserting rows with ABSOLUTE data displayed can cause the unexpected result of a non-zero value in the newly created row. This is normal and not an error.

INCREMENTAL DATA ROW INSERTION - EXPECTED ZEROS

Inserting empty rows of data is as simple as using the pop-up Insert an LRA row option. See this example:

Before insert:

	Length	Rotation	Bend	Radius
1	100.00	-----	90.00	50.00
2	100.00			
3	100.00			
4	100.00			
LL	100.00			



After Insert:

	Length	Rotation	Bend	Radius
1	100.00	-----	90.00	50.00
2	0.00	0.00	0.00	0.00
3	100.00	0.00	30.19	50.00
4	100.00	270.00	30.00	50.00
5	100.00	180.00	30.27	50.00
LL	100.00	-----	-----	-----

ABSOLUTE DATA ROW INSERTION - UNEXPECTED

Now if we change the Bend Calculation Setup to Absolute LENGTHS and perform the same insert, the results may be unexpected. In stead of "0.000" for the length, the inserted row shows "9.823".

This non-zero result is because the Absolute data is calculated from the foundational data of INCREMENTAL LRA data, and ABSOLUTE data depends on all previous rows of data for its calculation. This non-zero calculation is normal and should be expected.

Before Insert:

	Length	Rotation	Bend	Radius
1	900.00	-----	90.00	50.00
2	721.46	90.00	30.19	50.00
3	595.11	270.00	30.00	50.00
4	468.93	180.00	30.27	50.00
LL	100.00	-----	-----	-----

-  Copy Entire LRA Grid
-  Copy Selected Cells from LRA Grid
-  Copy LRA Grid in HTML Format
-  Paste to to LRA Grid
-  Paste Selection to LRA Grid
-  Insert an LRA Row
-  Delete an LRA Data Row
-  Print LRA Grid...
-  Set the LRA Grid Font...
-  Properties

After Insert:

	Length	Rotation	Bend	Radius
1	900.00	-----	90.00	50.00
2	821.46	0.00	0.00	0.00
3	721.46	0.00	30.19	50.00
4	595.11	270.00	30.00	50.00
5	468.93	180.00	30.27	50.00
LL	100.00	-----	-----	-----



Index

- " -

"A" 11
 "L" 11
 "R" 11

- . -

. 49

- 1 -

12 different styles 13

- A -

Absolute bender data 11
 Absolute Length radio button 25
 Absolute Length radius button 40
 absolute lengths 25
 Absolute Rotation radio button 31
 Absolute rotations 31
 accumulate 31
 apostrophe (') 29, 31, 38

- B -

Bend angles 38
 Bender data type setup 15

- C -

CAD programs 33
 Calc Setup 31
 Calc Setup button
 Bend Calculation Setup dialog 15
 Centerline radius values 41
 collet 33
 Combinations 13
 Compare Incremental to Absolute Rotations 31
 Compression bend 40
 Compression bend description 40

Conrac 11
 Conrac benders 25
 Conversion of values 47
 Cut Length 25

- D -

Database 47
 degree-minute-second format 29, 31, 38
 Draw bend 40
 Draw bend description 40

- E -

Effect of switching direction 33
 entry problems 17
 Entry range 29
 Error display 17
 example 29, 31, 38

- F -

FPB 11
 FRB 11

- H -

Hardware Key 5

- I -

Incremental data 11
 Incremental lengths 23
 Incremental Rotation radio button 29
 Incremental rotations 29
 Incremental versus absolute length 49
 Installing Bender to XYZ Software 5
 Internal storage 47
 inversion of all the Z values 33

- L -

letter "d" 29, 31, 38
 LRA 11

- M -

MIL-D-9898 11
military charts 11

- N -

negative errors 25
Negative incremental length 23
Negative values 29, 31, 38, 41
non-numeric 29, 31, 38
Non-numeric values 23, 41

- P -

Positive CW radio button 33
PRB 11
preceding rotations 31
proper order 29, 31, 38

- Q -

quotation mark (") 29, 31, 38

- R -

Range 31, 38
real-world 23
red bender cell 17
Rotation direction 33

- S -

Schwarze-Robitec dual-head benders 33

- T -

tape measure 25
twist angles 29

- U -

Unexpected row insertion results 49

- V -

valid ways to enter data 29, 31, 38

- X -

XYZ data charts 33

- Y -

YBC 11